## ShoreTel 110 IP Phone Quick Reference

#### PHONE OPERATION

#### **Placing Calls**

Place a Call

Make a Conference Call

Use the Intercom

Redial Last Number

Dial Paging Extension

### **Answering Calls**

Answer Call Waiting

Pick Up Another Call

Pick Up the Night Bell

## **Interacting with Calls**

Adjust the Volume

Mute a Call

Place a Call On or Off Hold

Transfer a Call

Park a Call

Unpark a Call

Silent Monitor

Barge In

Whisper Page

Change Call Handling Mode

#### **Change Extension Assignment**

**Unassign Your Ext. and Go Home** 

**Toggle the Hunt Group Status** 

lift handset + access code + number

while in a call + + ext. +

lift handset + + ext.

lift handset +

number provided by administrator

lift handset



lift handset + \* 1 3 + ext.

lift handset + \* 1 4



Mute

Transfer + ext. + hang up

+ \*11+ ext.

lift handset + \* 1 2 + ext.

lift handset + \*17 + ext.

lift handset + \* 1 6 + ext.

lift handset + \* 1 9 + ext.

lift handset + Voice Mail + pswd + # + 7 2

lift handset+ # # +ext+pswd+ # + 7 3 1

lift handset+ + pswd + # + 7 3 2

lift handset + \* 1 8 + hunt group ext.

### **Troubleshooting**

View Phone Information

Reboot Your Phone

#### **VOICE MAIL**

Logging Into Main Menu


**Logging In from Another Extension** 

Mute + I-N-F-O + #

lift handset + Voice Mail + pswd + #

# # + ext. + pswd + #

### 110 IP Phone with Third-Party Headset




#### To use a headset:

Connect a supported headset into the handset jack. Contact your system administrator for details.



# ShoreTel 110 IP Phone Quick Reference



110 IP Phone Interface

4:34 pm Mar 2

Time and Date

Time and Date
(Display alternates by showing extension)

inbound intercom calls.

NOTE: The IP110 is not a speak-

erphone, there is no external microphone.